

## PUMP ASSEMBLY & USAGE

# LUXURY SUPPORT® DIGITAL DELUXE AIR PUMP CONTROL OPERATION





### Luxury Support® Deluxe: 1 Wand, 3 Function (Up/Down/Memory), Dual System

- 1) Initial Setup Fill:** Press and release Memory key twice. Shortly after releasing Memory key the second time, pump will begin filling chamber. Factory preset is 50 mm/Hg. Repeat step one for other chamber if system is dual. Only one chamber may be filled at a time.
- 2) Manual Mode:** Soft/Deflate or Firm/Inflate keys may be pressed to manually set desired sleep preference.
- 3) To Reset Memory For Sleep Preference:** Press Soft/Deflate or Firm/Inflate to desired level. Press Memory key and hold Memory key until LED readout shows set point for sleep preference. Once Memory is set, to return to set preference, press and release Memory key twice and pump will adjust chamber accordingly shortly after key is released the second time. Repeat step three for other chamber if system is dual.
- 4)** Pump will stop operating at Memory set point or at 50 mm/Hg or if "hi" is displayed on readout or if pump has been running continuously for 10 minutes.
- 5) Energy Efficient Mode:** Display lights to turn off 5 minutes after use and relight after any keys are pushed.


**PLEASE NOTE:** While filling chambers it is normal for your Luxury Support® pump to turn off and on intermittently as it is allowing pressure to balance between pump and chambers to ensure accurate support set point readings.

When placing the pump under your bed, be sure to have the ports facing the wall after placing the air cores into the cavity of your new sleep system. Looking from the foot of your bed, the right side air core will be attached to the right port of your pump and the left side air core to the left port.



# TIPS

- If putting the pump on hardwood floors, place a towel under it to reduce vibration and noise.
- Place wired control in the center between the pillows for convenient access to both people.
- Do not over inflate air cores.
- Uncurl air core hose to ensure proper connection to air inflator.
- Plug into surge protector for added protection.



**\* KEEP THIS WITH YOUR MATTRESS \***